









ASSEMBLY INSTRUCTIONS

**ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE
INTENDED FOR RESIDENTIAL USE ONLY.**

TVS36LC

PARTS LIST

PART NO.	MATERIAL CODE	PART	Q'TY
1	TVS36LC-CS01	 TABLE TOP	1
2	TVS36LC-CS02	 LEG	4
3	TVS36LC-CS03	 CENTER CONNECTOR	1
4	33G???2CEZB0501	 GLASS	1

PART NO.	MATERIAL CODE	PART	Q'TY
5	17C17A0403001YX	 SCREW ST4.2*12	4
6	17C33A0706001YX	 BOLT M6*16	4
7	17FA05040301-YX	 WASHER d6.5*D13*1.0	4
8	17KAA0101----Y4	 HEX KEY WRENCH 4MM	1

You will need the following tools:

- Phillips Screwdriver (Not Included)




- Hex. Key Wrench (See Part #8)



Step 1:

Place the table top (#1) onto a non-abrasive surface, such as a carpet, with its underside facing upwards. Insert the legs (#2) into the plastic holders attached on the underside of the table top (#1) rim. Fasten them together by using screws (#5). See Figure 1.

FIGURE 1



- ⚠ Use the correct bolts as indicated. Do not tighten any of the bolts until the table is completely assembled.
- ⚠ Do not sit or stand on this table.
- ⚠ Do not discard any of the packaging until you have checked that you have all of the parts and fittings required.
- ⚠ Keep children away during assembly. This item contains small parts that can be swallowed by children. Children should always be under direct adult supervision while using this product.
- ⚠ Retain these assembly instructions for future reference.
- ⚠ Quote the following FQC NO. when contacting the service center.


SERVICE CENTER TOLL FREE NO.

TEL: 1-877-539-7436

FAX: 1-877-539-7439


COURTYARD CREATIONS INC.

FIGURE 2



Step 2:
Fasten the center connector (#3) to the middle of the legs (#2) by using bolts (#6) and washers (#7). Make sure that all of the bolts have been tightened completely. See Figure 2.

FIGURE 3



Step 3:
Turn the table to its upright position. Then put the glass (#4) onto the table top (#1) carefully. See Figure 3 and Figure 4.

FIGURE 4



Cleaning and Maintenance

- Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents.
- Wash glass with mild soap and water, rinse thoroughly, and dry completely.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your table.
- When moving the table, lift. Do not drag this table.
- Cover furniture with outdoor-furniture covers when not in use.
- In order to prolong the life and beauty of your table, we recommend that it be stored in a dry and protected area during off season periods.

Warranty

- This product is covered by Courtyard Creations Inc. One-year limited warranty.
- Proof of purchase (dated register receipt) is required for warranty claims.
- It remains the customer's responsibility for freight and packing charges to and from the service center.

STOP!

**Missing A Part?
No Need To Go Back To
The Store**

The store where you made your purchase does not stock parts for this item.

If you need parts, whether they are missing or damaged, Call Toll Free:

TEL: 1-877-539-7436

FAX: 1-877-539-7439

Call us between 9:00 AM and 4:30 PM Eastern Time Monday through Friday

For further assistance, please visit us at

service.cci@polywares.com

READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING ASSEMBLY

- ★ SEPARATE AND IDENTIFY ALL PARTS, MAKING SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
- ★ IF YOU DO NOT LOCATE ALL OF THE PARTS LISTED, INSPECT THE PACKING MATERIAL FOR SMALL PARTS THAT MAY HAVE BECOME SEPARATED DURING SHIPMENT.
- ★ IF YOU EXPERIENCE ANY DIFFICULTY DURING ASSEMBLY OR IF ANY PARTS ARE MISSING OR DAMAGED, CALL THE HELP LINE AT 1-877-539-7436 BEFORE RETURNING THIS ITEM TO THE STORE.
- ★ PROVIDE THE FOLLOWING INFORMATION WHEN CALLING:
1-MODEL NUMBER OF THE PRODUCT.
2-PART NUMBER AND MATERIAL CODE OF THE PART FROM THE PARTS LIST.
- ★ MOST PROBLEMS CAN BE RESOLVED WITHOUT RETURNING THIS PRODUCT TO THE RETAILER.