
IMPORTANT!! PLEASE READ ENTIRE INSTRUCTION SHEET BEFORE ASSEMBLY!! TO EXPEDITE ANY FUTURE WARRANTY CLAIMS, PLEASE KEEP INSTRUCTION SHEET, WARRANTY CARD AND RECEIPT

- **Step 1:** Remove all protective materials and set parts on a flat, non-abrasive surface. Identify parts packed in the carton against the parts list.
- **Step 2:** Attach a leg to the leg connector bracket by using a bolt and washer as shown in *Figure 1*. Guide the bolt through the hole in the leg, into the pre-drilled hole in the leg connector bracket. **Hand tighten only 2-3 turns.** Repeat for the other legs.





Step 3: Place the table rim upside down on a flat, non-abrasive surface. Attach a table leg to the table rim by using two bolts and washers as shown in *Figure 2*. Guide the bolts through the holes in the table leg into the pre-drilled holes in the table rim. Hand tighten only 2-3 turns. Repeat for the other legs.




Figure 2

Step 4: After making any necessary adjustments to the alignment of the table base and table top, use the hex bolt driver to tighten all bolts. Note: each bolt must be tightened a few revolutions at a time. In order to apply equal pressure to all bolt joints, we recommend working in a cross corner (X fashion). Repeat until all bolts are tight. Do not over tighten. Over tightening may strip bolts. Cover all bolts with covers.

Step 5: With the help of another person, turn the table in the upright position. Note the clear bumpers spaced evenly throughout the inside of the table rim. Carefully place glass inside the table rim, resting on the clear bumpers. Your table is now ready for use. * NOTE: PARTS SHOWN ON PARTS LIST ARE NOT TO SCALE

	PARTS LIST	DESCRIPTION	ORDER PART #	<u>QTY</u>
A		GLASS TOP		1
В		TABLE RIM	ST1919	1
С		LEG CONNECTOR BRACKET	ST1920	1
D	Amongana	TABLE LEG	ST1921	4
Е		1/4" X 20 MM BOLT	HW0036	12
F	0	Ø6.5 X 1.0 MM WASHER	HW0004	12
G		BOLT COVER	HW0105	12
Н		HEX BOLT DRIVER	HW0006	1
		FOOT CAP FACTORY ASSEMBLY	FC0069	
	Ð	TABLE BUMPER FACTORY ASSEMBLY	G0199	

BPH02610

CARE AND MAINTENANCE

FRAMES

Cleaning - Use mild soap and warm water. Do not use abrasive materials, cleansers or bleach products. Rinse with clean water and dry thoroughly.

Maintenance - Periodically clean and dry thoroughly. Be sure to drain any water accumulated inside the frames. To thoroughly drain frames, remove foot caps and tilt the frames, if necessary, to remove all water. This is critical. Water allowed to accumulate inside the frames and then exposed to sub-freezing temperatures can cause damage to the frame tubing. Such damage is not covered under warranty. Always clean, drain and dry thoroughly before storing for the winter. For best results, always store or cover your furniture when not in use. We recommend commercially available outdoor furniture covers. Any rust spots should be lightly sanded, treated with a commercially available rust inhibitor and followed by an application of touch-up paint. Any small nicks or scratches can be covered with a light application of touch-up paint.

** When cleaning or moving large or heavy items, always have two people work together. Never drag furniture.

GLASS

Use commercially available glass cleaners. Do not use abrasive materials, cleansers or bleach products.

SPECIAL WARNINGS!!!

GLASS WARNING!

Tempered glass is engineered to break safely into blunt pieces. However, broken glass pieces may still cause injury. PLEASE TAKE PRECAUTIONS AND DO NOT ALLOW ANYONE TO CLIMB, STAND, CRAWL OR WALK ON THE TOP OF THE GLASS TABLE. ALWAYS TAKE PRECAUTIONS TO PROTECT YOUR GLASS TABLE DURING STORMS AND HIGH WINDS.

LIMITED WARRANTY

- Frames. Frame construction is warranted against defects in materials or workmanship for one year from purchase date. Damage to frames or welds resulting from improper assembly or exposure to water and/or sub-freezing temperatures is not covered. General frame rusting is not covered.
- Finishes. Paint finishes are warranted against peeling, cracking or blistering for one year from purchase date provided the unit has not been scratched or abraded. Chips and scratches resulting from normal wear and tear are not covered.
- Fabrics. Fabric and cushions (if applicable) are warranted against separation at the seams for one year from purchase date. Fading and/or discoloration resulting from exposure to the elements, oils, spills, fluids, chemicals, or any other cause is not covered.
- Straps and/or wicker. Straps and/or wicker weave (if applicable) are warranted against separation and tearing for one year from purchase date. Fading and/or discoloration resulting from exposure to the elements, oils, spills, fluids, chemicals, or any other cause is not covered.
- Umbrellas. Umbrellas (if applicable) are warranted against manufacturer's defects only for one year from purchase date. Umbrella bases (if applicable) are not covered under any circumstances.
- Table tops. Natural stone tabletops only are warranted against defects in materials and workmanship only for one year from purchase date. All table tops (including without limitation glass and faux stone) are not covered under any circumstances.

Warranty limitations: This warranty is to the original purchaser only when purchased from one of our authorized dealers and is not transferable. We will pay shipping and handling charges for replacement items within the North American continent during the first year of ownership on all valid warranty claims. After the first year, shipping and handling charges are the responsibility of the claimant/owner. We shall not be responsible for charges associated with shipments outside of the North American continent at any time.

Warranty exclusions: The following are excluded from coverage under this limited warranty: any item used for commercial, contract or any other non-residential purpose; clearance items, display models or items purchased "as is"; freight damage; items subject to misuse, abuse, or lack of proper care or maintenance; damage caused by acts of nature, acts of force majeure, vandalism, fire or improper assembly; hardware against corrosion or rusting; purchased or replacement parts; and all plastic parts. Also excluded are loss of use or time; inconveniences; money, travel, packaging or incidental, special or consequential damages of any kind. Replacement of defective items as provided herein shall constitute the sole and exclusive remedy of the purchaser for items which are not as warranted. In no event shall our responsibility exceed the purchase price of the item found to be other than as warranted. This warranty is the exclusive statement of your rights with respect to defects in the items you have purchased and supersedes any other expressed warranty or statement, written or oral, made in connection with the purchase and sale of those items. When used herein, the term "item" refers to the specific item found to be defective, and not to the entire set of which the item is a part.

Some states do not allow exclusion or limitation of incidental or consequential damages, so that limitation above may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

PATIO FURNITURE & ACCESSORIES ASSEMBLY INSTRUCTIONS

IMPORTANT!!!

STOP! PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE ASSEMBLY. MAKE SURE YOU HAVE ALL THE PARTS AND HARDWARE AS IDENTIFIED ON THE PARTS LIST.

SCOV106