ASSEMBLY INSTRUCTIONS


ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE INTENDED FOR RESIDENTIAL USE ONLY.


KUS605P


PARTS LIST

PART NO.	MATERIAL CODE	PART	Q'TY
1	KUS605P-CS11-1	SEAT ASSEMBLY	1
2	KUS605P-CS04-1	BASE ASSEMBLY	1
3	17C40A0712001YX	BOLT M6*35	4

4	1808010345701	PLASTIC CAP	2
5	17KAA0101Y4	HEX. KEY WRENCH 4MM	1
6	61K605PX00001BA	BACK CUSHION	1
7	61K605PY00001BA	SEAT CUSHION	1








Step 2: At the front of the chair, fasten the seat assembly (#1) to the base assembly (#2) by using bolts (#3). Keep the bolts loose. See Figure 2.

Use the correct bolts as indicated. Do not tighten any of the bolts until the chair is completely assembled.

Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.

 Δ Keep children away during assembly. This item contains small parts that can be swallowed by children. Children should always be under direct adult supervision while using this product.




Retain these assembly instructions for future reference.

Quote the following FQC No. when contacting the service center.

SERVICE CENTER TOLL FREE NO. TEL: 1-877-539-7436


FAX: 1-877-539-7439

E-2



Step 3:

At the back of the chair, fasten the seat assembly (#1) to the base assembly (#2) by using bolts (#3). Make sure that all of the bolts have been tightened completely and cover them with plastic caps (#4). See Figure 3.



Step 4:

Place the cushions (#6 and #7) onto the chair. Secure the cushion to the chair by using the plastic clamps. You can adjust the leveler on base assembly (#2) to keep the chair even when it is not stable. See Figure 4.

Cleaning and Maintenance

- Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame parts.
- The cushion may be washed on the surface only by using mild soap and water or a commercial foaming upholstery cleaner if necessary. If washed, rinse well and hang to dry. Do not machine wash or dry.
- · We recommend the use of furniture covers when not in use.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure proper performance and safety of your chair.
- In order to prolong the life and beauty of your chair, we recommend that it be stored in a dry and protected area during off season periods.

Warranty

- This product is covered by Courtyard Creations Inc. one—year limited warranty.
- · Proof of purchase (dated register receipt) is required for warranty claims.
- It remains the customer's responsibility for freight and packing charges to and from the service center.

STOP!

Missing A Part? No Need To Go Back To The Store

If you need parts whether they are missing or damaged, Call Toll Free Call us between 9:00 AM and 4:30 PM Eastern Time Monday through Friday For further assistance

please visit us at

service.cci@polywares.com

READ THESE INSTRUCTIONS COMPLETELY BEFORE STARTING ASSEMBLY

- ★SEPARATE AND IDENTIFY ALL OF THE PARTS, MAKING SURE THAT YOU HAVE ALL OF THE PARTS LISTED.
- ★ IF YOU DO NOT LOCATE ALL OF THE PARTS LISTED, INSPECT THE PACKING MATERIAL FOR SMALL PARTS THAT MAY HAVE BECOME SEPARATED DURING SHIPMENT.
- ★IF YOU EXPERIENCE ANY DIFFICULTY DURING ASSEMBLY OR IF ANY PARTS ARE MISSING OR DAMAGED, CALL THE HELP LINE AT 1-877-539-7436 BEFORE RETURNING THIS ITEM TO THE STORE.
- ★ PROVIDE THE FOLLOWING INFORMATION WHEN CALLING: 1-MODEL NUMBER OF THE PRODUCT. 2-PART NUMBER AND MATERIAL CODE OF THE PART FROM THE PARTS.
- LIST. ★ MOST PROBLEMS CAN BE RESOLVED WITHOUT RETURNING THIS PRODUCT TO THE RETAILER.

PAGE 2 OF 2