



Assembly Instruction

TV Item No. 246312


STEP:1




STEP:2



STEP:3



STEP:4



Item	Photo	Description	Qty	Item	Photo	Description	Qty
A		The back of a chair	1	F		Allen screw (M6*15)	4
B		Pedestal	1	G		Allen screw (M6*30)	2
C		The left arm	1	H		Allen screw (M6*55)	2
D		Right arm	1	J		Allen Key	1
E		Washer (M6)	8				