

DO NOT RETURN TO RETAILER

IF YOU HAVE QUESTIONS OR CONCERNS

PLEASE CALL BOND TOLL FREE #

1-866-771-BOND (2663) OR TO BETTER

EXPEDITE YOUR REQUEST FEEL FREE TO EMAIL US

<u>customer.service@bondmfg.com</u>

OR VISIT OUR WEBSITE UNDER CUSTOMER
SERVICE SUPPORT

www.bondmfg.com




The Assembly Instruction for Wicker Arm Chair

Item No.: 69543

	Sketch	Description	Qty
А		Seat Panel	1
В		Back Panel	1
С		Right Armrest	1
D		Left Armrest	1
Е		Back Cushion	1
F		Seat Cushion	1
G		M6x35mm Bolt	12
Н	м6	Washer	12
I	M6	Wrench	1


Step 1

Attach the back panel (B) to the seat panel (A) by using 4pcs bolts (G) and 4pcs washers (H).




Step 2

Attach the seat panel (A) to both armrest (C&D) and back panel (B) by us ng 8 pcs bolts (G) and 8 pcs washers (H). Tighten all bolts with Wrench (I) provided.



Step 3

Finally put the cushions on. Assembly is complete.



For outdoor use only. RECOMMENDED CUSHION CARE MAINTENANCE:

For best results clean with mild soap and water and dry thoroughly to prevent water spots. Always clean prior to long term storage. Caution: Never use abrasive cleaners or bleach.

Note:

- 1. Please read these instructions carefully before assembly.
- 2. Indentify all parts packed in the carton against the parts list.
- 3. Do not fully tighten the bolts until all have been inserted and hand tightened.