

28 in. Fire Ring

PLEASE READ ALL RULES FOR SAFE OPERATION AND HELPFUL HINTS BEFORE USING.



WARNING: FUELS USED IN WOOD OR CHARCOAL BURNING APPLIANCES, AND THE PRODUCTS OF COMBUSTION OF SUCH FUELS, CAN EXPOSE YOU TO CHEMICALS INCLUDING CARBON BLACK, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, AND CARBON MONOXIDE, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE BIRTH DEFECTS OR OTHER REPRODUCTIVE HARM.

For more information go to: www.P65Warnings.ca.gov

Assembly and Use Instructions for Model: 25210 25215

VER. 1, 2/27/2019



# READ FIRST! RULES FOR THE MADDOX FIRE RING SAFE OPERATION.

- FOR OUTDOOR USE ONLY!
- USE THE FIRE RING ONLY ON STONE, DIRT OR SAND.
- DO NOT USE ON LAWNS, WOODEN DECKS, COMPOSITE DECKS, ASPHALT OR ANY COMBUSTIBLE SURFACE.
- KEEP THE FIRE RING A MINIMUM OF 10 FT. AWAY FROM BUILDINGS, STRUCTURES, ANY FLAMMABLE ITEMS AND VFHICI FS.
- NEVER USE UNDER LOW HANGING TREE BRANCHES, TRELLIS, OVERHANGS OR ANY COVERED STRUCTURES.
- WARNING! NEVER USE GASOLINE, ALCOHOL OR VOLATILE FLUIDS TO START OR RESTART FIRES.
- DO NOT USE THE FIRE RING WHILE IMPAIRED BY ALCOHOL OR ANY OTHER SUBSTANCE.
- DO NOT THROW FIREWOOD INTO THE FIRE RING, ADD FIREWOOD BY CAREFULLY PLACING INSIDE THE RING.
- THE FIRE RING IS FOR ADULT USE ONLY.
- ADULTS NEED TO KEEP WATCH AND SUPERVISE CHILDREN AND PETS WHEN AROUND THE FIRE PIT DURING USE.
- KEEP LOOSE CLOTHING AWAY.
- DO NOT LEAVE UNATTENDED AT ANY TIME WHILE IN USE.
- DO NOT USE IN WINDY CONDITIONS!
- DO NOT OVERLOAD OR USE FOR BURNING GARBAGE.
- USE CAUTION WHEN TENDING THE FIRE, AS SURFACES WILL BE HOT WHILE IN USE.
- BEFORE EACH USE MAKE SURE FIRE RING IS IN GOOD WORKING CONDITION.
- USE CAUTION AFTER THE FIRE HAS BEEN EXTINGUISHED, SURFACES WILL REMAIN HOT FOR SOME TIME.
- CHECK LOCAL LAWS AND CODES BEFORE USING.

## A

#### **HELPFUL HINTS FOR USAGE**

- DO NOT ATTEMPT TO MOVE THE FIRE RING ONCE THE FIRE IS STARTED. MAKE SURE THE FIRE RING IS IN POSITION BEFORE STARTING THE FIRE.
- BE COURTEOUS ON WHERE THE FIRE RING IS PLACED. DO NOT PLACE WHERE THE FIRE RING COULD BE EASILY TRIPPED OVER.
- FOR BEST RESULTS, STACK FIREWOOD IN A PYRAMID SHAPE FOR BURNING.
- DO NOT USE FIREWOOD OVER 24 IN. LONG.



#### **CARBON MONOXIDE HAZARD!**

BURNING WOOD OR CHARCOAL PRODUCES CARBON MONOXIDE, WHICH HAS NO ODOR AND CAN CAUSE DEATH IF BURNED IN ENCLOSED AREAS. NEVER BURN WOOD OR CHARCOAL INSIDE HOMES, VEHICLES, TENTS OR ANY OTHER ENCLOSED AREAS.

DO NOT RETURN
PRODUCT TO THE
STORE. IF YOU HAVE
QUESTIONS OR HAVE
TROUBLE WITH
ASSEMBLY, PLEASE
CALL 1-800-321-3473
FOR ASSISTANCE.


Congratulations on your purchase of the Fire Ring! At Landmann USA, we strive to provide you with an easy to use, easy to assemble product. However, in the unlikely event your package should have a missing or defective part, please contact us at:

customerservice@landmann-usa.com

1-800-321-3473 M-F 8-5 Eastern Time Proof of purchase may be required. Thank you!


#### **PARTS LIST**

When unpacking the Fire Ring from the carton, make sure you find and become familiar with all the parts listed below. Use caution as some parts may have sharp edges.



A Phillips screwdriver is needed for assembly.

Assembly time: 5 minutes



**x** 8

(8) M6 x 10MM BOLTS



(8) M6 FLANGED HEXNUTS

#### **ASSEMBLY INSTRUCTIONS**


LANDMANN. Fire Ring

STEP 1

### ASSEMBLE THE RING SECTIONS

Take any (4) ring sections [A] and assemble with (8) 10MM bolts [B] and (8) flanged hexnuts [C]. Tighten bolts and hexnuts securely.







NOTE! THE FIRE RING IS MADE ONLY TO CREATE A BOUNDARY RING FOR THE FIRE AND IS NOT MADE TO CONTAIN A FIRE.



RESTART FIRES

WARNING!

HOT SURFACES DURING
USEI USE MITTENS,
POKER OR GLOVES ON
THESE PARTS.

Please visit our website at: www.landmann.com/us -OR-Call customer service toll free at: 1-800-321-3473

Landmann® Limited
Distributed by Landmann® USA
Fairburn, GA 30213
www.landmann.com/us
Made in China
© 2019 Landmann® USA