



## **Assembly Instruction**

SKU#258743     Product Name: 30" Round Fire Pit (FT-1103E)

### **Safety Information:**

PLEASE READ AND UNDERSTAND THIS ENTIRE MANUAL BEFORE ATTEMPTING TO ASSEMBLE, OPERATE OR INSTALL THE PRODUCT.

### **WARNINGS:**


- This fire bowl is intended for outdoor use only. Do not use on wooden decks.
- This fire bowl is intended to burn wood logs only. Do not burn coal, leaves, or other combustible materials in the fire bowl.
- Not for use by children. Keep children and pets away from the fire bowl.
- The fire bowl is hot. Use with caution. Do not touch the hot fire bowl with bare hands.
- Never leave the burning fire bowl unattended, and always extinguish the fire completely before leaving the fire bowl.
- Do not use near flammable or combustible objects or materials.
- When the fire bowl is in use, the handle on the mesh screen can reach extreme temperatures that can cause serious injury to an unprotected hand. Use a poker or an appropriate heat resistant glove or pad when handling.
- Check local fire regulations and municipal by-laws for safe use.
- Some parts may contain sharp edges—especially as noted in the manual. Wear protective gloves if necessary.

## FIRE PIT PARTS LIST


No.	PARTS	Qty
A	Handle	1
B	Mesh cover	1
C	Wood grate	1
D	Cover support	4
E	Fire bowl	1
F	Legs	4
G	Upper ring	1
H	Lower ring	1
I	Poker	1

## HARDWARE LIST

No.	Hardware	Qty
AA	M6 x14 Bolt	4
BB	M6 x10 Bolt	8
CC	M6 x10 Bolt	4
DD	M6 Nut	5




### Pre-Assembly:




### TOOLS REQUIRED (Not included)

## **Step By Step Assembly Instructions:**


**Step1:** Insert handle (A) into hole in Mesh cover (B) and tighten it with M6 Nut (DD) underside to secure.




**Step 2:** Attach the legs (F) to the Upper ring (G) by using M6 x 10 mm bolts (BB) ,then tighten the bolts.








**Step 3:** Attach the legs (F) to the Lower ring (H) by using M6 x 14 mm bolts (AA), then tighten the bolts.



**Step 4:** Attach the Cover support(D) to the Fire bowl (E) by using M6 x 10 mm Stainless steel bolts (CC) and M6 Nut (DD), then tighten the bolts.



**Step 5:** Put the Fire bowl(E), Wood grate(C), Mesh cover(B). Place the poker (I) near the fire pit for use anytime.



### **Operating Instruction:**

WARNING: Before using this outdoor firepit, make sure you have read, understand and are following all information provided in the important Safeguards presented on page 1. Failure to Follow those instructions can cause death, serious injury or property damage.

### **Extinguishing:**

- Allow fire to burn out.
- Do NOT use water to extinguish as this is dangerous and can cause damage to the fire pit.

### **Care and Cleaning:**

- Do not attempt to clean the fire pit until the fire is completely out and cooled.
- Use a soft cloth to wipe the fire pit and poker.
- Do not attempt to clean while hot.

### **Storage:**

- Do not attempt to move the fire pit while it is hot or in use.
- Store assembled in a cool, dry location away from children and pets.
- Keep the fire pit covered when cooled and not in use.

### **Warning :**

FUELS USED IN WOOD OR CHARCOAL BURNING APPLIANCES, AND THE PRODUCTS OF COMBUSTION OF SUCH FUELS, CAN EXPOSE YOU TO CHEMICALS INCLUDING CARBON BLACK, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, AND CARBON MONOXIDE, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE BIRTH DEFECTS OR OTHER PRODUCTIVE HARM.

For more information go to: [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov).

### **6 Month Limited Warranty:**

This product is warranted for 6 months against any defects in material and workmanship. Normal wear or damage due to abuse, mishandling or unauthorized repairs are not covered. This warranty does not apply to accessories. This warranty gives you specific legal rights which vary from state to state. For all warranty claims, contact Customer Care: 855-600-9294 (8:00am to 8:00pm EST) or by email: [customercare@china-yayi.com](mailto:customercare@china-yayi.com).

### **GARANTÍA LIMITADA DE 6 meses**

Este producto tiene una garantía de 6 meses contra cualquier defecto en materiales y mano de obra. El desgaste normal o los daños debidos a abuso, mal manejo o reparaciones no autorizadas no están cubiertos. Esta garantía no se aplica a los accesorios. Esta garantía le otorga derechos legales específicos que varían de estado a estado. Para todas las reclamaciones de garantía, comuníquese con Atención al Cliente: 855-600-9294 (de 8:00 am a 8:00 pm EST) o por correo electrónico: [customercare@china-yayi.com](mailto:customercare@china-yayi.com).

#### **6 MONTHS LIMITED WARRANTY**

Manufactured for and distributed  
by True Value Company  
Chicago, IL 60631-3505  
©2019 True Value Company

Fabricado para y distribuido por  
la empresa True Value® Company  
Chicago, IL 60631-3505  
©2019 True Value Company

Four Seasons Courtyard™  
is a trademark of the  
True Value Company  
Made in China

Four Seasons Courtyard®  
es una marca comercial de True  
Value Company  
Hecho en China