

Instruction Manual

SKU#258744 Product Name: 30" Round Fire Pit (FT-51214)


PLEASE READ AND UNDERSTAND THIS ENTIRE MANUAL BEFORE ATTEMPTING TO ASSEMBLE, OPERATE OR INSTALL THE PRODUCT.

WARNINGS:

- This fire bowl is intended for outdoor use only. Do not use on wooden decks.
- This fire bowl is intended to burn wood logs only. Do not burn coal, leaves, or other combustible materials in the fire bowl. Do NOT burn over 5lbs untreated wood or fire logs in this fire pit.
- Not for use by children. Keep children and pets away from the fire bowl.
- The fire bowl is hot. Use with caution. Do not touch the hot fire bowl with bare hands.
- Never leave the burning fire bowl unattended, and always extinguish the fire completely before leaving the fire bowl.
- Do not use near flammable or combustible objects or materials.
- When the fire bowl is in use, the handle on the mesh screen can reach extreme temperatures that can cause serious injury to an unprotected hand. Use a poker or an appropriate heat resistant glove or pad when handling.
- Check local fire regulations and municipal by-laws for safe use.
- Ensure all ashes are completely cool before removal.
- Some parts may contain sharp edges—especially as noted in the manual. Wear protective gloves if necessary.


FIRE PIT PARTS LIST

No.	PARTS	Qty
Α	Handle	1
В	Mesh cover	1
С	Wood grate	1
D	Fire bowl	1
E	Connect ring	1
F	Leg	4
G	Poker	1




HARDWARE LIST

No.	Hardware	Qty
AA	M6x 8 mm Bolt	12
BB	M6 Nut	1




Pre-Assembly:




TOOLS REQUIRED (Not included)

Step By Step Assembly Instructions:


Step 1: Attached the handle (A) to mesh (B) cover using M6 nut (BB).




Step 2: Connect the legs (F)to the fire bowl (D) using M6*8mm(AA) bolts .Don't not tighten the bolts at this step .



Step 3: Connect the connection ring (E) to the legs(F)using M6 x 8mm bolts (AA). Do not tighten the bolts until all bolts in right place. Tighten each bolt after assembly is completed.



Step 4: Place grate (C)and assembled mesh cover (B) on the fire bowl. Place the fire poker (G) next to the firepit. The fireplace is ready for use.



Operating Instruction:

WARNING: Before using this outdoor firepit, make sure you have read, understand and are following all information provided in the important Safeguards presented on page 1. Failure to Follow those instructions can cause death, serious injury or property damage.

Extinguishing:

- Allow fire to burn out.
- Do NOT use water to extinguish as this is dangerous and can cause damage to the fire pit.

Care and Cleaning:

- Do not attempt to clean the fire pit until the fire is completely out and cooled.
- Use a soft cloth to wipe the fire pit and poker.
- Do not attempt to clean while hot.

Storage:

- Do not attempt to move the fire pit while it is hot or in use.
- Store assembled in a cool, dry location away from children and pets.
- Keep the fire pit covered when cooled and not in use.

Warning:

FUELS USED IN WOOD OR CHARCOAL BURNING APPLIANCES, AND THE PRODUCTS OF COMBUSTION OF SUCH FUELS, CAN EXPOSE YOU TO CHEMICALS INCLUDING CARBON BLACK, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE CANCER, AND CARBON MONOXIDE, WHICH IS KNOWN TO THE STATE OF CALIFORNIA TO CAUSE BIRTH DEFECTS OR OTHER PRODUCTIVE HARM.

For more information go to: www.P65Warnings.ca.gov.

6 Month Limited Warranty:

This product is warranted for 6 months against any defects in material and workmanship. Normal wear or damage due to to abuse, mishandling or unauthorized repairs are not covered. This warranty does not apply to accessories. This warranty gives you specific legal rights which vary from state to state. For all warranty claims, contact Customer Care: 855-600-9294 (8:00am to 8:00pm EST) or by email:customercare@china-yayi.com.

GARANTÍA LIMITADA DE 6 meses

Este producto tiene una garantía de 6 meses contra cualquier defecto en materiales y mano de obra. El desgaste normal o los daños debidos a abuso, mal manejo o reparaciones no autorizadas no están cubiertos. Esta garantía no se aplica a los accesorios. Esta garantía le otorga derechos legales específicos que varían de estado a estado. Para todas las reclamaciones de garantía, comuníquese con Atención al Cliente: 855-600-9294 (de 8:00 am a 8:00 pm EST) o por correo electrónico: customercare@china-yayi.com.

6 MONTHS LIMITED WARRANTY
Manufactured for and
distributed by True Value
Company Chicago, IL 60631-3505
© 2019 True Value Company

Four Seasons Courtyard™ is a trademark of the True Value Company Made in China Fabricado para y distribuido por la empresa True Value® Company Chicago, IL 60631-3505 ©2019 True Value Company

Four Seasons Courtyard®
es una marca comercial de True
Value Company
Hecho en China