four seasons
COURTYARD®

Coral Bay 4 PC Woven Deep Seating Set - Coffee Table
Assembly Instructions

Step 1: Remove protective wrapping and lay all parts on floor. Identify all parts packed in carton against attached parts list.

Step 2: Assemble Side Brace Panel (J) to Leg Pair (I) with Bolt (EE) and Washer (CC) using Allen Wrench (DD).

Step 3: After Brace Panels and Legs are securely attached together, place table in upright position. Then lay Glass Top (FF) onto top of table, making sure it sits flat and securely inside table frame.

Note: When assembly chair together, loosely thread bolts into all attachment points first to make sure all parts and bolts fit in proper position. Afterwards, go back and securely tighten all bolts accordingly.

It is user's responsibility to ensure all bolts are tightened securely before turning chair to upright position and using chair.


Diagram 1

Diagram 2

Diagram 3

Parts List:

Ref	Part Name	Part Image	Qty	Ref	Part Name	Part Image	Qty
I	Leg Pair		2	DD	Allen Wrench (M6)		1
J	Side Brace Panel		2	EE	Bolt (M6x25)		8
CC	Washer (M6)		8	FF	Glass		1

1 YEAR LIMITED WARRANTY

This product is warranted for 1 year against any defects in material and workmanship. If defective, the product will be repaired or replaced free of charge. Simply provide proof of purchase and return the product to your placem of purchase. Normal wear or damage due to abuse, mishandling, or unauthorized repairs is not covered. The warranty does not apply to accessories. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

For customer service, please call 1-800-877-2290
Hours of operation: Monday-Friday 8:00am - 5:00pm CST
Email: retail3@woodard-furniture.com